

# **PSS / PROFESSIONAL SALES AND SERVICE, L.C.**

Quality Emergency Vehicles Since 1974

April 25, 2024

Albany Fire Department  
1000 San Pablo Avenue  
Albany, CA 94706

To Whom It May Concern:

Professional Sales and Service, LC respectfully provides the Albany Fire Department the following estimate for a new ambulance vehicle. We appreciated the opportunity to work with you now and look forward to helping you with your ambulance needs in the future.

The following proposal reflects a new Type I ambulance equipped with similar options and feature configuration to the Horton ambulance discussed with you in previous conversations. The proposal is as follows:

## **One (1) 2023 Horton 457F Type I 2WD Custom Ambulance Mounted on a 2023 Ford F-450 4x2 Diesel Chassis**

The module body will be 157" long and have an interior height of 72" inches. It will be mounted on a 2023 Ford F-450 4x2 with a Diesel Motor dual rear wheel cab/chassis. This proposal includes Horton's electrical system: The I4g – The most advanced electrical system available which incorporates solid-state electronics with Multiplexing technology. It also includes weight saving all-aluminum module body, NO-wood construction, aluminum cabinetry, electrical system diagnostic testing, digital computer consoles, privacy windows, LED lighting package and much more. Full specification attached.

Take a look at Horton Emergency Vehicles (HEV) and you will see why they are so well regarded in the ambulance industry and among the finest available anywhere. A Horton emergency vehicle is BUILT TO WITHSTAND the rigors of ambulance service. Horton ambulances are tested and engineered to be incredibly structurally sound which provides the EMS crew and patient with a SAFER WORKING ENVIRONMENT. They are currently the only manufacturer with an ongoing crash simulation testing program to test things like cabinet mounting stability, door structure & latching strength, and body mounting solidity. ALUMINUM CABINETS SAVE PAYLOAD and are much more DURABLE than wood. An ambulance built to a higher quality standard will provide REDUCED OPERATING COSTS over the many years the vehicle is in service!! When it comes to quality, durability, customization, and safety, Horton continues to be a leader in the ambulance manufacturing industry.

### **PSS SHOWROOM**

1720 Indiana Ave, Salt Lake City, UT 84104  
(801) 977-3961 Phone <> (801) 977-3969 Fax

# **PSS / PROFESSIONAL SALES AND SERVICE, L.C.**

Quality Emergency Vehicles Since 1974

## **PRICING CONDITIONS**

<b><u>Ambulance Price*</u></b>	<b><u>\$347,505.00</u></b>
<b><u>Shipping</u></b>	<b><u>\$4,800.00</u></b>
<b><u>Tire Fee (\$1.75 each)</u></b>	<b><u>\$12.25</u></b>
<b><u>Factory Inspection ( 2 Dept. Personal )</u></b>	<b><u>\$3,500.00</u></b>
<b><u>Price (1) One Ambulances</u></b>	<b><u>\$355,817.25</u></b>
<b><u>Sales Tax at 10.75%***</u></b>	<b><u>\$37,872.78</u></b>
<b><u>Total Price (1) One Ambulance with Tax</u></b>	<b><u>\$393,690.03</u></b>

\*Price is as per Sourcewell Contact # 122123-RVG  
Note old Sourcewell Contract # 110921-HAL

\*\*\*Sales tax rate subject to be adjusted to actual sales tax at time of delivery or payment  
whichever comes first.

### **PSS SHOWROOM**

1720 Indiana Ave, Salt Lake City, UT 84104  
(801) 977-3961 Phone <> (801) 977-3969 Fax

# **PSS / PROFESSIONAL SALES AND SERVICE, L.C.**

Quality Emergency Vehicles Since 1974

## **PROPOSAL CONDITIONS**

**F.O.B. POINT:** Albany, CA 94706

**DELIVERY:** Do to current and on going national supply chain issues specifically in regards to chassis availability. We will be providing estimated delivery times only. Currently Horton standard lead time is approximately 24 months (pending chassis). Please note all delivery times are quoted barring any delays due to strikes, availability of component parts (including chassis), or acts of God

!! Available chassis and production spot. Due to chassis availability and productions spots. If a chassis is selected that is on the ground and available Delivery at the factory can be expected, within 12 -14 months from final sign off of the spec.

**SERVICE:** Professional Sales & Service has been selling and servicing ambulances since 1975. We have factory trained technicians and a large inventory of parts, so you know that in the unlikely event of a problem we are only a phone call away.

**PAYMENT TERMS:** Payment due upon delivery and acceptance of vehicle by the Albany Fire Department

\*\* Pre-Payment Discounts available upon request.

**WARRANTY:** Horton Emergency Vehicles feature one of the most progressive, no-nonsense warranties around. Horton does not pro rate their warranties so there are no surprises should you ever need it.

### ***PSS SHOWROOM***

1720 Indiana Ave, Salt Lake City, UT 84104  
(801) 977-3961 Phone <> (801) 977-3969 Fax

# **PSS / PROFESSIONAL SALES AND SERVICE, L.C.**

Quality Emergency Vehicles Since 1974

*Unless accepted within Sixty (60) days from the above date, the right to withdraw this proposal is reserved. If there are any additions/deletions to our bid, please contact me for pricing details or credits.*

We are confident you will be completely satisfied with a quality Horton ambulance and the service which PSS provides.

Respectfully Submitted,

Professional Sales and Service, LC

*Braxton T. Peterson*

Braxton T. Peterson, General Manager

Albany Fire Department agrees to purchase the vehicle detailed in this proposal, from Professional Sales and Service, L.C. and understands and agrees with the terms specified within these documents.

---

Authorized by (Print name)

---

Signed

---

Date

Please let us know if you have any questions regarding this proposal. We are happy to assist you in any way that we can.

**PSS SHOWROOM**

1720 Indiana Ave, Salt Lake City, UT 84104  
(801) 977-3961 Phone <> (801) 977-3969 Fax

September 25, 2023



## PRELIMINARY BUILD SPECIFICATION

Quote # QUO0000008781

Production #

Document Rev. # 1

Status: Draft

**Prepared For:**

..  
ALBANY FIRE DEPARTMENT  
1001 MARIN AVENUE  
ALBANY,  
CA  
94706  
Phone:

**Presented By:**

Braxton Peterson  
Professional Sales and Service  
762 South Redwood Road  
Salt Lake City, UT  
84104  
Phone: (801) 977-3961

Option	QTY	Description
<b>CHASSIS</b>		
<b>1000-0002</b>	<b>1</b>	<b>AMBULANCE SPECIFICATIONS</b>
<b>SR00239613</b>	<b>1</b>	Previous Vehicle Reference -  Reference previous vehicle #18530.
<b>1000-1064</b>	<b>1</b>	<b>CHASSIS, 2024 FORD F-450 4X2, 169, DIESEL</b> The chassis required to complete the ambulance conversion shall be supplied by Horton. F4G F-450 REGULAR CHASSIS DRW 4X2 663A XLT TRIM 99T 6.7L 4 VALVE OHV POWER STROKE V8 TURBO DIESEL B/20 ENGINE INCLUDES DIESEL EMISSIONS FLUID (DEF) 44G TORQSHIFT TEN-SPEED AUTOMATIC 169" (84" cab to axle) Full Spec Attached
<b>1000-0068</b>	<b>1</b>	<b>Paint Chassis SPECIAL COLOR Pierce #90 Color code N4664EA</b> The chassis is to be ordered special color from chassis OEM.
<b>1000-0071</b>	<b>1</b>	<b>CHASSIS ORDERED WITH ALUMINUM WHEELS</b> The specified chassis is to be ordered to include OEM aluminum wheels.
<b>SR00239623</b>	<b>1</b>	Chassis Options -  Install All-Terrain tires on the chassis.
<b>1000-0451</b>	<b>1</b>	<b>PASS THROUGH CAB/MODULE, F SERIES</b>

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		Install a pass-through opening between the cab and module. Pass-through to include a bellows connection.
1000-0067	1	<b>DIESEL EXHAUST FLUID FILL, F SERIES</b> Install a label next to the DEF fill stating that the fill is to be used for DEF only.
1000-0083	1	<b>STANDARD CAB HEIGHT</b> The specified chassis will have the standard cab height.
1000-0346	1	<b>MUD FLAPS, REAR, LARGE W/LOGO</b> Install individual rear mud flaps behind each set of rear wheels. Mud flaps to include Horton logo.
1000-0090	1	<b>REINFORCE REAR BUMPER END CAPS</b> Reinforce end caps of rear bumper for greater impact resistance.
1000-0204	1	<b>RUNNING BOARDS: EMBOSSED ALD. F SERIES</b> Install heavy duty aluminum embossed diamond plate running boards and splash shields.
1000-0105	1	<b>REAR TOW HOOKS</b> Install (2) tow hooks rear of vehicle. Attach to bumper frame.
SR00239603	1	<b>Install a Columbus style rear bumper that is Embossed.</b>
1000-0144	1	<b>LIQUID SPRING SUSPENSION, F 450</b> Install a Liquid Spring hydraulic rear suspension. Wire system to dump when the left rear entry door is opened. Install manual controls in the cab near the driver.
3000-0407	1	<b>RECEIVER/DRYER KIT, FORD F-SERIES CHASSIS</b> Install standard receiver/dryer kit w/pressure switch in the air conditioning system.
<b>BODY</b>		
SR00239604	1	<b>CUSTOM BODY WIDTH:</b> Reduce the body width 2" to 94.25" wide. Note this affects all compartments and cabinet depths
2000-0047	1	<b>AMBULANCE BODY</b> Conversion model is to be a 457-I using a Ford F Series chassis. Body length is 157".
2000-0013	1	<b>HEADROOM, 72"</b> The headroom is to be 72".
2000-0625	1	<b>ALUM. DIAMONDPLATE AT SIDE STEPWELL</b> Fabricate the stepping surface inside the side access door using polished aluminum diamond treadplate.
2000-0243	1	<b>DOUBLE STEP CURBSIDE ENTRY, 3" DROP SKIRT</b> <p>Fabricate curbside of body with 3" drop skirt. To include two step side entry.</p>
2000-0244	1	<b>STREETSIDE 3" DROP SKIRT</b> Fabricate streetside of body with 3" drop skirt.
2000-0250	1	<b>SOUND PROOFING/ACOUSTIC ENHANCEMENT PACKAGE</b> Install standard sound control package.
2000-1050	1	<b>ROOF POCKET, AUXILIARY CONDENSER</b> Install a roof pocket for a CoolTech I unit.
2000-0259	1	<b>PRIVACY WINDOWS, FIXED, REAR ENTRY DOORS</b>

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		Install privacy tinted solid fixed windows in the rear module access doors.
2000-0263	1	<b>PRIVACY WINDOW, SLIDING FOR SIDE ENTRY DOOR</b> Install a sliding tinted privacy window in the side access door.
2000-0265	2	<b>EMERGENCY RELEASE, REAR DOORS</b> Install standard emergency release knobs on top and bottom of the rear module entrance doors.
2000-0704	1	<b>EMERGENCY RELEASE, SIDE ACCESS DOOR</b> Install emergency release knobs on top and bottom of the side module entrance door.
2000-0010	1	<b>DOOR HANDLES</b> Install Tri-Mark free floating style door handles with pre-stretched stainless steel cables. Include three piece interior door panels on all access doors.
2000-0811	1	<b>VI-TECH MOUNTING, F SERIES</b> Install standard Vi-Tech body mounts.
2000-0270	1	<b>MIRROR STAINLESS STEEL SPLASH SHIELDS</b> Install #8 mirror stainless splash shields on the lower front face of the body just behind the cab access doors. These splash shields are to be the same height as the diamond plate front corner guards.
2000-0688	1	<b>FENDERS, STAINLESS, STD, CS 3" DROP SKIRT</b> Install a stainless steel fender, for use in conjunction with a 3" drop skirt, at the curbside rear wheelwell location.
2000-0689	1	<b>FENDERS, STAINLESS, STD, SS 3" DROP SKIRT</b> Install a stainless steel fender, for use in conjunction with a 3" drop skirt, at the streetside rear wheelwell location.
2000-0273	1	<b>POLISHED STAINLESS RUB RAILS</b> Polished stainless lower body rub rails, with #8 mirror finish, are to be installed along the bottom of the body on each side fore and aft of the rear wheels.
2000-0652	1	<b>STANDARD CORNER GUARDS</b> Install standard height polished diamondplate corner guards.
2000-0281	1	<b>REAR DOOR HOLD OPENS, GRABBER</b> Install chrome Cast Products "Grabber" style rear door hold opens. (NOTE: HOLDOPENS MUST BE RELOCATED IF TELESCOPIC LIGHTS ARE ORDERED)
2000-0584	1	<b>REAR RISER ADP</b> The rear riser is to be fabricated out of polished aluminum diamondplate.
2000-0684	1	<b>LICENSE PLATE BRACKET, CENTER OF RISER</b> Install a recessed rear license plate bracket centered in the rear riser. Include an LED license plate light.
2000-0598	20	<b>DOOR REFLECTORS</b> All patient compartment entry doors to include standard red reflectors.
<b>COMPARTMENTATION</b>		
2900-1440	1	<b>STREETSIDE FORWARD COMPARTMENT</b> The height of the streetside front compartment is to be the reduced from full height due to location of ducted A/C. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
2000-0400	1	<b>SS FORWARD COMPT. DIAMONDPLATE</b> The streetside forward compartment is to be fabricated from diamondplate.
2000-0225	1	<b>SWEEP OUT COMPARTMENT FLOOR, SS FRONT</b> Streetside forward compartment floor is to be sweep-out style.
2900-0095	1	<b>SILL PLATES, STREETSIDE FRONT</b> Install a stainless sill plate on the streetside forward compartment.
2900-1441	1	<b>STREETSIDE INTERMEDIATE COMPARTMENT</b> The height of the streetside intermediate compartment is to be the full available height to the bottom of the interior countertop. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2000-0402	1	<b>SS INTRMDT COMPT. DIAMONDPLATE</b> The streetside intermediate compartment is to be fabricated from diamondplate.
SR00239611	1	<b>STREETSIDE INTERMEDIATE COMPARTMENT MODIFICATION: Raise the top of the compartment 14" to just under the attendant counter top</b>
2900-0144	2	<b>ADJUSTABLE SHELF STREETSIDE INTERMEDIATE Center in the compartment</b> Install diamond plate adjustable shelving in the streetside intermediate compartment. Locate as noted.
2000-0587	1	<b>CEILING MOUNTED ELECTRICAL EQUIPMENT</b> Add-on electrical equipment is to be installed on the ceiling of the streetside intermediate compartment.
2900-0252	1	<b>EXPANDED METAL CAGE, STREETSIDE INTERMEDIATE</b> Install an expanded metal cage around the onboard electrical equipment per location noted above. Include access ports to equipment with grip lock around the edges of the openings.
2900-4005	1	<b>SILL PLATES, STREETSIDE INTERMEDIATE</b> Install a stainless sill plate on the streetside intermediate compartment.
2900-1448	1	<b>STREETSIDE REAR COMPARTMENT</b> The height of the streetside rear compartment is to be 1/4 of the available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and double hinged doors.
2000-0404	1	<b>SS REAR COMPT. DIAMONDPLATE</b> The streetside rear compartment is to be fabricated from diamondplate.
SR00239617	1	<b>STREET SIDE REAR HEIGHT MODIFICATION: Increase compartment height 38".</b>
SR00239609	1	<b>STREETSIDE REAR COMPARTMENT NOTCH:</b> The upper 24" of the compartment is to have a setback creating a 13.36" deep upper exterior area and room for 6" OD deep interior cabinets. The tool mounting plate will be mounted on this surface.
2900-0145	1	<b>ADJUSTABLE SHELF STREETSIDE REAR Center in lower full depth area</b> Install diamond plate adjustable shelving in the streetside rear compartment. Locate as

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**



Option	QTY	Description
		noted.
<b>2900-0216</b>	<b>1</b>	<b>TOOL MOUNTING PLATE; STREETSIDE REAR</b> Install a .25" thick aluminum plate on the back wall of the streetside rear compartment. Plate is to have a D/A finish. Install (2) aluminum 'C' channels to the wall and secure the plate using the 'C' channels.
<b>SR00239600</b>	<b>1</b>	The tool board in the street side rear compartment is to have peg board holes.  .25" HOLES ON A 1"X1" GRID
<b>2900-4007</b>	<b>1</b>	<b>SILL PLATES, STREETSIDE REAR</b> Install a stainless sill plate on the streetside rear compartment.
<b>2900-1450</b>	<b>1</b>	<b>CURBSIDE REAR COMPARTMENT</b> The height of the curbside rear compartment is to be full available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
<b>2000-0409</b>	<b>1</b>	<b>CS REAR COMPT. FLAT ALUMINUM</b> The curbside rear compartment is to be fabricated from flat aluminum.
<b>2900-0149</b>	<b>1</b>	<b>FIXED SHELF CURBSIDE REAR Bottom shelf to right of fixed divider, 42" above the floor</b> Install a fixed diamond plate shelf in the curbside rear compartment using (4) cast shelf brackets, (2) for right wall, (2) for left wall. Install cast brackets directly to the compartment walls. Locate shelf as noted.
<b>2900-0148</b>	<b>1</b>	<b>ADJUSTABLE SHELF CURBSIDE REAR Center in space above fixed shelf.</b> Install diamond plate adjustable shelving in the curbside rear compartment. Locate as noted.
<b>2900-4070</b>	<b>2</b>	<b>FIXED VERTICAL DIVIDER, CURBSIDE REAR First full height divider 13.75" from right wall, Second 42" tall divider, 10" left of the right wall</b> Install a 16" deep fixed vertical divider in the curbside rear compartment. Locate as noted above.
<b>2900-4001</b>	<b>1</b>	<b>STAIR CHAIR POCKET, CURBSIDE REAR</b> A stair chair pocket is to be recessed into the curbside rear compartment inner door panel. The pocket shall be installed as close to the bottom and hinged side of door as possible. See drawings for dimensions.
<b>2900-2956</b>	<b>1</b>	<b>STAIR CHAIR MODEL, STRYKER #6252</b> A Stryker #6252 stair chair will be stored as noted. This is for sizing/placement purposes only. Horton is not to supply this equipment.
<b>SR00239633</b>	<b>1</b>	<b>CURBSIDE REAR COMPARTMENT OPTION: Install an upper backboard restraint brace. (Matted)</b> Locate: Left of the full height divider, 70" above the compartment floor.
<b>2900-4008</b>	<b>1</b>	<b>SILL PLATES, CURBSIDE REAR</b> Install a stainless sill plate on the curbside rear compartment.
<b>2900-1449</b>	<b>1</b>	<b>CURBSIDE INTERMEDIATE COMPARTMENT</b>

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		Install a compartment between the curbside rear compartment and the wheel house. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2000-0406	1	<b>CS INTRMDT COMPT. DIAMONDPLATE</b> The curbside intermediate compartment is to be fabricated from diamondplate.
2900-4009	1	<b>SILL PLATES, CURBSIDE INTERMEDIATE</b> Install a stainless sill plate on the curbside intermediate compartment.
2900-1454	1	<b>CURBSIDE FORWARD COMPARTMENT</b> The height of the curbside front compartment door is to be the full available height of the body. See drawings for door dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2900-4010	1	<b>SILL PLATES, CURBSIDE FRONT</b> Install a stainless sill plate on the curbside forward compartment.
2900-0110	1	<b>RUBBER MATTING IN EXTERIOR COMPARTMENTS</b> Ribbed black rubber matting will be installed on the floor and shelves of all exterior compartments.
2900-1206	1	<b>RUBBER WALLS IN BB COMPT, BLACK</b> The interior of the backboard compartment is to be covered with black rubber matting to protect equipment stored in this area.
<b>PAINT AND GRAPHICS</b>		
5000-0189	1	<b>MODULE PAINT Paint Custom Color to match Chassis Pierce #90 Color code N4664EA</b> The module body is to be painted a special paint color and paint code as noted above.
SR00239621	1	Paint the mod roof white from the drip rails up.  Paint the cab white from window level up including the A and B pillars.
5000-0500	1	<b>PAINT 360 DEGREE CAMERA COVERS</b> The 360 Degree camera covers are to be painted to match the body color.
SR00239622	1	<b>DG CHEVRON, REAR PANELS - YELLOW #983-71/RED: Install Diamondgrade chevron striping on the rear of the body inboard of the corner posts and below the upper drip rail. Exclude rear entry doors.</b>
SR00239601	1	<b>Install Red/White chevrons on the center sections of the entry doors.</b>
<b>INTERIOR FEATURES</b>		
2000-0288	1	<b>ACRYLIC COLOR: LIGHT TINT</b> All acrylic doors to be light tint.
2000-0825	1	<b>COUNTERTOP, MERAPI Standard Locations</b> Install solid surface countertop(s) in lieu of stainless steel. Material is to include radiused and tapered corners and is to have a polished finish. Color is to be Merapi. Locate as noted above.
2000-0299	1	<b>STAINLESS STEEL-INHALATION AREA WALLS:</b> The rear and side walls bordering the inhalation area are to be covered with brushed stainless steel.

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
2000-0303	1	<b>INHALATION PANEL, LAMINATE COVERED</b> The inhalation panel is to be fabricated from composite material and covered with laminate to match to color selected.
SR00239616	1	<b>O2 PANEL NOTE: O2 panel is to be a 10" deep straight panel and as short as possible.</b>
2000-0457	1	<b>LONCOIN FLECKSTONE Gray Stone Moonstone</b> The patient area floor is to be covered in Loncoin Fleckstone Gray Stone Moonstone 157TS.
SR00239615	1	<b>Cabinet Wall Riser -</b>  Install stainless steel on the interior risers. If a cabinet riser accent stripe is ordered the stainless steel will stop at the bottom edge of the stripe. The cabinet wall riser will extend up to the cabinets.
2000-0325	1	<b>STAINLESS STEEL LOWER DOOR PANELS</b> Finish lower section of inside patient compartment doors with stainless steel.
2000-0441	1	<b>WILSONART FASHION GRAY #D381, WALLS</b> The interior walls are to be made of reinforced structural composite board covered with Wilsonart Fashion Gray #D381 laminate. This does not apply to areas surrounding the inhalation/CPR seat area.
2000-0667	1	<b>FASHION GREY CABINET COLOR</b> All interior cabinetry is to be painted Fashion Grey.
2000-0710	1	<b>CABINET PAINT TO BE TEXTURED</b> The specified cabinet paint is to have a textured finish.
2000-0946	1	<b>PATRIOT PLUS DOVE GRAY VINYL COLOR</b> All seat cushions, backrests and vinyl closeouts are to be covered in Patriot Plus Dove Gray colored material.
2000-0326	1	<b>STANDARD FIXED SEATBASE</b> Install the standard aluminum fixed seat base for the attendant's seat specified.
2000-3139	1	<b>USSC, BLACK 4-POINT, DOVE GRAY WITH CHILD SEAT</b> Install a Dove Gray #8567 USSC high back bucket seat with built-in child safety seat and black 4pt seatbelt with safety vest. The seat to be adjustable front to rear and is to be mounted at the head of the cot.
2000-1754	1	<b>OCCUPANT RESTRAINT. HEAD OF BENCH, BLACK</b> Install an MBrace 4-pt seatbelt at the head position of the squad bench. Color is to be black.
2000-1758	1	<b>OCCUPANT RESTRAINT. FOOT OF BENCH, BLACK</b> Install an MBrace 4-pt seatbelt at the foot position of the squad bench. Color is to be black.
2000-1762	1	<b>OCCUPANT RESTRAINT. CPR SEAT, BLACK</b> Install an MBrace 4-pt seatbelt at the CPR seat position. Color is to be black.
2000-0605	1	<b>ALUMINUM INTERIOR CABINETS</b> All interior cabinets are to be fabricated from aluminum.
3000-1119	1	<b>TUBULAR AIRBAG, ATTENDANT'S SEAT</b> Install a tubular airbag at the attendant's seat. Unit uses an angled upper inhalation

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		cabinet and includes a cabinet beneath the main countertop.
<b>3000-1122</b>	<b>1</b>	<b>HEAD CURTAIN AIRBAG, ATTENDANT'S SEAT</b> Install a head curtain airbag at the attendant's seat for use with a deleted or modified linen cabinet.
<b>3000-1126</b>	<b>1</b>	<b>AIRBAG SENSOR</b> Install the standard airbag sensor in the standard location.
<b>3000-1127</b>	<b>1</b>	<b>TUBULAR AIRBAG, CPR SEAT LOCATION.</b> Install a tubular airbag forward of the CPR seat.
<b>2000-0575</b>	<b>1</b>	<b>CABINET TRIM RADIUS</b> Install smooth radiused trim molding on all applicable interior cabinets.
<b>2900-0211</b>	<b>1</b>	<b>IV HANGER, CP WITH RUBBER ARM COT WAIST over the cot waist area.</b> Install a Cast Products recessed IV hanger with rubber arm over the cot waist area.
<b>2000-0414</b>	<b>1</b>	<b>GRAB RAIL: (2) 2FT ANTI MIC. OVER COT Per Drawing</b> Install (2) standard style 2' main grab rails with anti-microbial coating. Locate offset toward the main wall over the cot position in the patient area ceiling.
<b>2000-0622</b>	<b>1</b>	<b>GRAB RAIL: 8FT ANTI-MIC CENTER Locate curbside edge of the center ceiling plate.</b> Install a standard style 8' main grab rail with anti-microbial coating. Locate centered in the patient area ceiling.
<b>2000-0418</b>	<b>1</b>	<b>VERTICAL GRAB RAIL, 2' ANTI-MICROBIAL BOLSTER</b> Install a standard style 2' grab rail with anti-microbial coating. Locate on the bench bolster at the side access door angled upward toward the forward end.
<b>2000-0419</b>	<b>1</b>	<b>PATIENT DOOR GRAB RAILS: ANTI-MICROBIAL</b> Install standard 'V' shaped grab rails with anti-microbial coating. Locate on the interior door panels of all three patient entry doors.
<b>2000-0423</b>	<b>1</b>	<b>CEILING MATERIAL, PLATINUM WHITE COMPOSITE</b> The standard module ceiling material shall be platinum white aluminum composite.
		.
<b>SR00239636</b>	<b>2</b>	Technimount 35 for Physio Control 15 Monitor -  Install a Technimount 35 for Physio Control 15 Monitor . Locate in the inhalation area left of the attendant panel. Just forward of the CRP seat  Install a Technimount 35 for Physio Control 15 Monitor . Locate at the head of the beach above the drawer stack.
<b>STREETSIDE CABINETRY</b>		
<b>SR00239635</b>	<b>1</b>	<b>LINEN CABINET NOTE: A CUSTOM CLOSEOUT IS NECESSARY FOR HEAT/AC BOX.</b>
<b>2000-0337</b>	<b>1</b>	<b>LINEN CABINET</b> Install a standard storage cabinet behind the attendant seat.
<b>2900-1078</b>	<b>1</b>	<b>FIXED SHELF, LINEN CLOSET, CENTER SECTION</b>

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		Fab and install a fixed aluminum shelf in the middle section of the linen cabinet. Shelf is to be painted to match the cabinet color.
<b>2900-1081</b>	<b>1</b>	<b>ADJUSTABLE SHELF MIDDLE 2 LINEN CLOSET</b> Fab and install a second adjustable aluminum shelf in the middle section of the linen cabinet. Shelf is to be painted to match the cabinet color.
<b>2900-1083</b>	<b>1</b>	<b>ADJUSTABLE SHELF LOWER LINEN CLOSET</b> Fab and install an adjustable aluminum shelf in the lower section of the linen cabinet. Shelf is to be painted to match the cabinet color.
<b>2900-2029</b>	<b>1</b>	<b>SOLID LAMINATE-COVERED LINEN CLOSET DOOR</b> Install hinged solid doors on the linen cabinet. Cover in laminate to match the interior.
<b>SR00239625</b>	<b>1</b>	<b>LINEN CLOSET MODIFICATION: Install vent in bottom of linen cabinet door.</b>
<b>2900-1072</b>	<b>1</b>	<b>PIANO HINGE FOR LINEN CLOSET MIDDLE DOOR</b> The middle linen cabinet door(s) is/are to use piano style hinge.
<b>2900-1184</b>	<b>1</b>	<b>SOUTHCO LATCH, MIDDLE LINEN, CHANGE 10</b> Install a stainless flush mount Southco pull latch on the middle linen cabinet door. <b>Latch to be Change Notice 10 compliant and rated for 25lbs.</b>
<b>2000-0343</b>	<b>1</b>	<b>STREETSIDE WALL WITH CPR SEAT</b> Street side cabinet wall to include a CPR seat.
<b>2000-0310</b>	<b>1</b>	<b>CPR SEAT, 28" WIDTH</b> Streetside CPR seat width to be 28".
<b>2900-4089</b>	<b>1</b>	<b>ANGLED UPPER CABINET, FORWARD OF CPR SEAT</b> The upper cabinet forward of the CPR seat is to be angled with .25" aluminum door and steel catch. The cabinet is to be Change Notice 10 compliant.
<b>2900-4088</b>	<b>1</b>	<b>ANGLED UPPER CABINET, AFT OF CPR SEAT</b> The upper cabinet to the rear of the CPR seat is to be angled with .25" aluminum door and steel catch. The cabinet is to be Change Notice 10 compliant.
<b>SR00239632</b>	<b>1</b>	Lips on shelves -  Do not install the tall lips on the front edge shelves of the 3 upper streetside cabinets.
<b>2000-2050</b>	<b>1</b>	<b>CUSTOM CABINET, Cabinet 1 Dimensions: 48.75"W x 10.75"H X 15"D - Location: Street side Upper Rear</b> Main wall cabinet #1 dimensions are to be as noted above. Note that dimensions are I.D.
<b>2000-1360</b>	<b>1</b>	<b>POLYCARBONATE SLIDING, CHANGE 10, CABINET 1</b> Cabinet specified above is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch and angled corner brackets.
<b>2900-0061</b>	<b>1</b>	<b>INTERIOR ADJUSTABLE SHELVING Cabinet 1</b> Install painted adjustable shelving in cabinet #1.
<b>2000-2051</b>	<b>1</b>	<b>CUSTOM CABINET, Cabinet 2 Dimensions: 48.75"W X 22.75"H X 4"D - Location: LOWER REAR</b> Main wall cabinet #2 dimensions are to be as noted above. Note that dimensions are I.D.

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
2000-0521	1	<b>ACRYLIC SLIDING, Cabinet 2</b> Cabinet specified above is to have sliding 3/8" acrylic doors.
2900-1709	1	<b>ACRYLIC HINGED DOORS, Cabinet 2</b> Cabinet specified above is to have two 1/2" acrylic vertically hinged doors.
2900-0172	1	<b>INTERIOR ADJUSTABLE SHELVING, Cabinet 2</b> Install painted adjustable shelving in cabinet #2.
2000-2052	1	<b>CUSTOM CABINET, Cabinet 3 Dimensions: 28"W x 5H X 15"D - Location: Above CPR seat</b> Main wall cabinet #3 dimensions are to be as noted above. Note that dimensions are I.D.
2900-2198	1	<b>ACRYLIC HINGED DOOR, Cabinet 3</b> Cabinet specified above is to have a 1/2" acrylic top hinged flip-up door.
2900-0282	2	<b>LATCH, HINGED DOOR: SOUTHCO SS Cabinet 3</b> Install stainless flush mount Southco pull latches on the selected hinged doors on the cabinet designated above.
2900-0330	3	<b>COMPRESSION STYLE HINGE Cabinet 3</b> Cabinet #3 door(s) is/are to use compression style hinges.
2900-0410	1	<b>LIFT UP CABINET FRAMES, UPPER INHALATION CABINET</b> Install a flip-up restocking cabinet frame on cabinet noted above. Includes gas shocks and vertical latches. <b>The Design is to be compliant with Change Notice 10.</b>
2000-2058	1	<b>UPPER INHALATION CABINET 38.75"W x 10.75"H X 15."D</b> Upper inhalation cabinet dimensions are to be as noted above. Note that dimensions are I.D.
2000-1368	1	<b>POLYCARBONATE SLIDING, UPPER INHALATION, CHANGE 10</b> Cabinet over inhalation area is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch.
2900-1094	1	<b>INTERIOR SHELVING, UPPER INHALATION CABINET</b> Install painted adjustable shelving in upper inhalation cabinet.
<b>CURBSIDE CABINETRY</b>		
2000-0359	1	<b>SQUAD BENCH WITH NO CUPS OR WELLS</b> Provide storage under the squad bench lid/cushion(s). The area shall run where possible under the bench. The storage pan is to be fabricated from aluminum and painted to match the interior.
2000-0367	1	<b>SQUAD BENCH END RESTRAINT, BOLSTER</b> Install a standard HOPS bolster at the head end of the bench.
SR00239639	1	Head of bench cabinet.  Install a custom cabinet with counter at head of bench attached to bolster wall. This is to have (2) rear facing drawer and custom sharps/waste drawer. The sharps/waste drawer is to open into the stepwell area to remove the containers. There should be openings above the drawer to put the waste and sharps int. Drawer to be approx 18"D ID. The overall height of the cabinet to be 39" Area between the sharps/waste to be angled for additional bench length and access to the sharps container. Angle to be approx 45 degrees, allowing for a clearance of 9.29" minimum. The upper drawers to be rear facing that is 13.25"W x 3"H x 13"D ID. Construct both drawer with .190" aluminum ILOS.

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
<b>2000-0743</b>	<b>1</b>	<b>SINGLE CUSHION SQUAD BENCH</b> The squad bench cushion is to be one piece.
<b>2000-0380</b>	<b>1</b>	<b>BENCH HOLD OPENS: GAS</b> Install gas spring hold opens on squad bench lid.
<b>2000-0585</b>	<b>1</b>	<b>BENCH HOLD-DOWN: PADDLE LATCHES (SINGLE)</b> Install a recessed paddle latch into the squad bench riser to retain the squad bench lid in the closed position.
<b>2000-1791</b>	<b>2</b>	<b>BENCH BACK CUSHION, DOVE GRAY</b> The MBrace backrest cushions for the bench seating positions are to be Dove Gray #8567 in color. Seat cushion and closeout colors are listed separately.
<b>2000-1796</b>	<b>1</b>	<b>CPR SEAT BACK CUSHION, DOVE GRAY</b> The MBrace backrest cushions for the CPR seat are to be Dove Gray #8567 in color. Seat cushion and closeout colors are listed separately.
<b>SR00239602</b>	<b>1</b>	Leave space at the forward end of the bench wall for the dealer to install a Horton provided (Ship Loose) PD-7 Paramedic Design holder. The bench cushion will run all the way to the bolster.
<b>2000-0516</b>	<b>1</b>	<b>S/W ON A TIP OUT DOOR, FORWARD BENCH</b> Install a tip-out under the head of the squad bench facing the aisle. This door will house both sharps and waste containers. Containers are to be supplied by Horton. Paint cabinet to match interior.
<b>2900-0052</b>	<b>1</b>	<b>BENCH CABINET, HINGED DOORS &amp; O2 OUTLET</b> Fabricate and install a bench ceiling cabinet above the squad bench with lift up Plexiglas doors. The forward portion is to include space for one O2 outlet.
<b>2900-1130</b>	<b>2</b>	<b>SOUTHCO LATCH OVERHEAD BENCH CABINET</b> Install stainless flush mount Southco pull latches on the bench ceiling cabinet.
<b>2900-1135</b>	<b>6</b>	<b>SELF CLOSING HINGE FOR OVERHEAD BENCH CABINET</b> The bench ceiling cabinet door(s) is/are to use self-closing style hinges.
<b>SR00239610</b>	<b>1</b>	<b>GLOVE STORAGE SIDE ENTRY INNER DOOR PANEL:</b> Install a surface mount diamond plated glove box storage holder on the Lower inner panel of the curbside entry door per drawing Configure to accommodate 3 standard glove boxes.
<b>FRONT WALL CABINETRY</b>		
<b>2900-0074</b>	<b>1</b>	<b>FRONT WALL CABINET, DIAMOND PLATE INTERIOR</b> The front wall cabinet shall be arranged per drawing. Additional configuration information may follow. Cabinet interior is to be polished aluminum diamondplate.
<b>SR00239630</b>	<b>1</b>	<b>GLOVE STORAGE ABOVE FRONT WALL CABINET:</b> Storage for (2) glove boxes shall be provided in the header above the front wall cabinet. The face of the storage area will be covered in matching interior vinyl and include openings for access to each storage area. The header will be hinged for restocking or removal of glove boxes.

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		This lowers the cabinet 2"
2900-1737	1	<b>ACRYLIC HINGED DOORS, Upper front wall</b> Cabinet specified above is to have two 1/2" acrylic vertically hinged doors.
SR00239608	1	<b>Install a Southco rotary latch on the upper front wall cabinet doors. Latch to be Change Notice 10 compliant and rated for 40lbs.</b>
2900-1017	6	<b>SELF CLOSING HINGES TOP FRONT WALL CABINET</b> The upper front wall cabinet door(s) is/are to use self-closing style hinges.
2900-1038	1	<b>ADJUSTABLE SHELF, UPPER FRONT WALL TOP CABINET</b> Fab and install an adjustable aluminum shelf in the upper section of the front wall cabinet as noted. Shelf is to match the cabinet interior.
2900-1039	1	<b>FIXED SHELF FRONT WALL MIDDLE CABINET</b> Fab and install a fixed aluminum shelf in the center section of the front wall cabinet as noted. Shelf is to match the cabinet interior.
2900-1042	1	<b>ADJUSTABLE SHELF, LOWER FRONT WALL CABINET</b> Fab and install an adjustable aluminum shelf in the lower section of the front wall cabinet as noted. Shelf is to match the cabinet interior.
2900-1745	1	<b>ACRYLIC HINGED DOORS, Lower front wall</b> Cabinet specified above is to have two 1/2" acrylic vertically hinged doors.
SR00239614	1	<b>Install a Southco rotary latch on the lower front wall cabinet doors. Latch to be Change Notice 10 compliant and rated for 40lbs.</b>
2900-1021	6	<b>SELF CLOSING HINGES LOWER FRONT WALL CABINET</b> The lower front wall cabinet door(s) is/are to use self-closing style hinges.
SR00239605	1	<b>CROSSOVER CABINET:</b> Install a crossover cabinet above the walk through/pass through. Include a solid hinged door with locking southco latch. This cabinet will house the electronics/brain. Max W x 18"H x 12"D
<b>COT MOUNT</b>		
2000-0600	1	<b>POWER LOAD, RAIL ONLY, CENTERED Cot Type: Stryker Power Pro XT</b> Supply and install a floor plate assembly kit only for a Stryker Power load system. Locate in the center position. Note: this option does not comply with GSA change notice 8. Certification cannot be provided unless Horton installs the entire mount assembly.
<b>VISUAL WARNING</b>		
3000-1805	1	<b>WIG WAG HEADLIGHTS, F SERIES</b> Install wig wag headlight flasher. Provide a dedicated switch in the front control panel. Deactivate in secondary mode.
3200-0072	2	<b>M9, WHITE, CLEAR LENS Front body face, Light bar alternative</b> Install Whelen M9 series LED lights as noted. Lights to be white with clear lenses. Lights to

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**



Option	QTY	Description
		include chrome flanges and flash pattern programmability from the front control panel.
<b>3300-5016</b>	<b>2</b>	<b>M9 AMBER/CLEAR LENS Module rear Upper outer corners</b> Install Whelen M9 series LED lights as noted. Lights to be amber with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>3000-5104</b>	<b>1</b>	<b>M7 Amber/Clear Lens Rear Center KKK</b> Install a Whelen M7 series LED light centered on the rear face of the body above the rear doors. Light is to be amber with a clear lens. Light is to include a chrome flange and flash pattern programmability from the front control panel.
<b>3000-5018</b>	<b>5</b>	<b>M9 RED/CLEAR LENS Front face: (1) center, (2) each side of white lights</b> Install Whelen M9 series LED lights as noted. Lights to be red with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>3400-5018</b>	<b>2</b>	<b>M9 RED/CLEAR LENS Rear of body at window level</b> Install Whelen M9 series LED lights as noted. Lights to be red with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>3500-5018</b>	<b>4</b>	<b>M9 RED/CLEAR LENS (2) Curbside of body, (2) Streetside of body</b> Install Whelen M9 series LED lights as noted. Lights to be red with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>SR00239626</b>	<b>1</b>	<b>Program the front face center red M9 light to steady burn in primary and secondary mode ILO flash.</b>
<b>3000-0144</b>	<b>1</b>	<b>FLASH PATTERN, 80 FPM A/B</b> Program the emergency lighting flash pattern to 80 FPM A/B.
<b>3000-1017</b>	<b>1</b>	<b>RED/CLEAR LENS, WHELEN ION GRILLE, TOP</b> Install (2) Whelen ION Series red LEDs with clear lenses in the upper chassis grille. To include bezels where applicable and flash pattern programmability from the front control panel.
<b>3000-1263</b>	<b>1</b>	<b>RED/RED LENS 500 TIR6 LED INT. LIGHTS</b> Install (2) Whelen 500 TIR6 Series red LED lights with red lenses on the chassis fenders. To include housings and weather proof plugs.
<b>AUDIBLE WARNING</b>		
<b>3000-0182</b>	<b>1</b>	<b>SIREN, FEDERAL EQ2B</b> Install a Federal EQ2B siren in the front console.
<b>3000-1856</b>	<b>1</b>	<b>SIREN, FEDERAL RUMBLER, F SERIES</b> Install a Federal Rumbler low frequency siren.
<b>3000-1543</b>	<b>1</b>	<b>SPEAKERS, CAST PRODUCTS, F SERIES</b> Install Cast Products siren speakers, applicable to Ford F-Series chassis, in the front bumper.
<b>NON-EMERGENCY LIGHTING</b>		
<b>3000-0208</b>	<b>1</b>	<b>KKK SIDE BODY MARKER LIGHTS, M6 SERIES LED (PAIR)</b> Install red Whelen M6 series LED turn/marker lights on each rear side of the module body. Lights provide module body night time side lighting visibility and turning signal indication. Lights do not flash with warning lights unless otherwise specified. Includes chrome flanges.
<b>3000-0217</b>	<b>1</b>	<b>LED EXTERIOR COMPARTMENT LIGHTING</b>

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		Install full height LED strip lighting in all exterior compartments with the exception of any wheelwell compartments. Install vertical strips inside both sides of each compartment. The lights are to be directed toward the back of each compartment.
3000-0847	1	<b>WHELEN OS SERIES MARKER LIGHTS.</b> Install Whelen OS series ICC marker lights.
3000-0240	1	<b>M9 SERIES LED SCENE LIGHT, STREETSIDE FRONT</b> Install a Whelen M9 LED side scene light with chrome flange on the upper streetside forward portion of the body.
3000-0741	1	<b>M9 SERIES LED SCENE LIGHT, STREETSIDE REAR</b> Install a Whelen M9 LED side scene light with chrome flange on the upper streetside rear portion of the body.
3000-0748	1	<b>M9 SERIES LED SCENE LIGHT, CURBSIDE FRONT</b> Install a Whelen M9 LED side scene light with chrome flange on the upper curbside forward portion of the body.
3000-0762	1	<b>M9 SERIES LED SCENE LIGHT, CURBSIDE REAR</b> Install a Whelen M9 L.E.D. side scene light with chrome flange on the upper curbside rear portion of the body.
3000-1633	1	<b>LOAD LIGHTS, M9 SERIES LED</b> Install two Whelen M9 LED load lights with chrome flanges above the rear body entry doors.
3000-1438	1	<b>TAIL LIGHTS, M6 SERIES, HORIZONTAL MOUNTED</b> Install Whelen M6 series LED stop/tail, turn, and reverse lights. Install the stop/tail and reverse lights in the rear riser/kick plate with brake/tail outboard. Install the turn signals above in the rear body panels. Lights to include chrome flanges.
<b>ELECTRICAL</b>		
3000-0018	1	<b>ELECTRIC DOOR LOCKS COMPARTMENT EXTERIOR</b> Install power activated door locks on all exterior compartment doors. Locks to be activated by a switch at each patient area access door. Locks may be overridden by a door key.
3000-0019	1	<b>ELECTRIC DOOR LOCKS ACCESS DOORS INTERIOR</b> Install power activated door locks on all patient area access doors. Locks to be activated by a switch at each patient area door. Locks may be overridden by a manual slide lever or by the door key.
3000-0022	1	<b>ELECTRIC DOOR LOCKS WIRED TO OEM SWITCHES</b> The specified power door locks are to be wired to the chassis OEM door lock switches.
3000-0451	1	<b>ELECTRIC DOOR LOCKS CONCEALED LICENSE PLATE</b> Install a concealed switch in the license plate bracket to operate the power door lock circuit. Doors shall be wired to unlock only on this circuit.
3000-0026	1	<b>REAR RADIO SPEAKERS OVER REAR DOORS</b> Install two (2) rear AM/FM radio speakers in the patient compartment over the rear doors. Provide volume control in the rear switch panel.
3000-0401	1	<b>ELECTRICAL SYSTEM</b> Install the Intelliplex i4G+ electrical system.
3000-0305	1	<b>INPOWER BATTERY SWITCH, WITH WAKE BUTTON 5 min.</b>

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		Install an Inpower electronic battery switch. Switch is to activate battery power through the vehicle ignition and is to include an automatic shutdown timer to deactivate battery power after the ignition is turned off. To include a wake button installed on the front console to activate the electrical system without using the key.
3000-0310	4	<b>110V INTERIOR OUTLET 1 In Inhalation Area, &amp; 1 In Mid Front Wall Cabinet, 1 in the street side intermediate compartment, 1 in the street side over fender compartment.</b> Install a 110V outlet(s) as noted.
3000-0549	4	<b>INTERIOR 12VDC OUTLETS: CL TYPE/USB 1 Inhalation Area, 1 Mid Front Wall Cabinet, 1 upper Front wall cabinet, and 1 in the street side intermediate compartment</b> Install a 12VDC cigarette style/USB outlet(s) as noted. Wire battery hot.
3000-1462	1	<b>SHORELINE 1, 20A SUPER AUTO EJECT, RED</b> Mount a Kussmaul Super Auto Eject 20 amp shoreline inlet in the standard location. Cover is to be red.
3000-1501	1	<b>PD BOX LOCATION, BEHIND DRIVER'S SEAT</b> Install the power distribution box behind the driver's seat.
3000-0328	1	<b>KUSSMAUL EZ PLATE, 20A SUPER AUTO EJECT #1</b> Install a Kussmaul EZ Plate for the selected 15/20A Super Auto Eject shoreline #1.
3000-0327	1	<b>EXTRA 12VDC CIRCUIT BREAKER: INTERMEDIATE COMPT</b> An extra circuit breaker shall be installed in the streetside intermediate compartment.
3000-0332	1	<b>REPORT LIGHT, LED</b> Install a 12" LED report light on the action wall to light the counter area.
3000-0344	1	<b>STEP WELL LIGHT VISTA LED</b> Install a 10.5" LED Vista light strip in the standard location on the bench side of the step well. Light to activate with door open.
3000-0346	1	<b>2.5" CAB CEILING LIGHTS, WHITE/RED LED</b> Install (2) combination white/red LED dome lights in the cab headliner. Locate one light over the driver and one light over the passenger. Wire to a switch in the front control panel and provide 'OFF', 'CLEAR' and 'RED' selections.
3000-0360	7	<b>PATIENT CEILING DOME LIGHTS, CODE 3 VITAL VIO</b> Code 3 Vital Vio dome lights in the patient area ceiling.
3000-0524	1	<b>3 SWITCH PANEL OVERHEAD OF BENCH</b> Install an i4G 3-switch control panel on the bench curbside wall over the head of the bench.
3000-2102	1	<b>TIMER, DOME LIGHTS, OVERHEAD BENCH</b> Install an electronic momentary touch timer switch in the specified I4g switch panel on the wall over the head of the squad bench. The switch will enable time limited operation of the specified dome lights with the battery switch in the 'off' position. Set timer to 15 minutes.
3000-0525	1	<b>3 SWITCH PANEL REAR DOOR PANEL</b> Install an i4G 3-switch control panel on the right rear entry door panel.
3000-2103	1	<b>TIMER, DOME LIGHTS, REAR DOOR PANEL</b> Install an electronic momentary touch timer switch in the specified I4g switch panel on the right rear door panel. The switch will enable time limited operation of the specified dome lights with the battery switch in the 'off' position. Set timer to 15 minutes.
3000-5042	1	<b>DUMP OVERRIDE, i4G, REAR DOOR PANEL</b>

Spec Writer: John Cox

Spec Designer:

Albany Fire Department

Option	QTY	Description
		Install the dump override switch in the panel selected for the right rear entry door inner panel.
3000-5062	1	<b>LOAD LIGHT SWITCH, i4G, REAR DOOR PANEL</b> Install load light control switch in the panel selected for the right rear entry door inner panel.
SR00239620	1	<b>O2 SWITCH: Add a switch to the bench switch cluster for O2 activation.</b>
3000-0601	1	<b>SPOT LIGHT: HAND HELD: ON REAR CAB WALL</b> Install a Star-Lite LED hand held spotlight with momentary switch on the bulkhead behind the driver's seat.
SR00239599	1	PREWIRE FOR STREAMLIGHTS: QTY: 2 Locate: Streetside Intermediate Compartment, W/3' service loop. Configure: Constant Hot  Locate: Streetside Rear Compartment, W/3' service loop. Configure: Constant Hot
SR00239627	1	PREWIRE FOR FUTURE KNOX MED VAULTS: Quantity: 1 Locate: Upper front wall cabinet - left side. Configure: constant hot
SR00239598	1	Back up alarm switch -  Install a separate back up alarm reset switch on the front console not in the i4G screen.
3000-0012	1	<b>REVERSE PROXIMITY SYSTEM</b> Install a Brigade reverse proximity system.
3000-1905	1	<b>360 CAMERA SYSTEM, WHITE</b> Install a Horton 360 Degree camera system with white covers and integral lighting. The lighting is to have the ability to function in emergency response mode. The display will function in conjunction with the turn signals and when the vehicle is in reverse gear. Install rear housing if space is available. If space is unavailable then install camera only.
SR00239618	1	Install a mirror replacement monitor for the 360 camera system, RVS-619NQ  The back up camera should be on any time the vehicles ignition is on with the 360 view in the split part of the monitor.
<b>PROGRAMMING</b>		
6000-0002	1	<b>LIGHT PROGRAMMING: RIGHT SIDE SCENE</b> The right side scene lights shall come "on" when the side patient door is opened.
6000-0003	1	<b>LIGHT PROGRAMMING: LOAD LIGHT</b> Program the rear load lights to activate with transmission reverse plus the standard mode of operation.

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
6000-0006	1	<b>PROGRAMMING: AUDIBLE LOW VOLTAGE ALARM</b> Program an audible alarm to activate if the voltage drops below 11.8 volts for 120 seconds.
6000-0007	1	<b>LIGHT PROGRAMMING: PARK BRAKE</b> Program a warning to display on the front console readout advising to set the Parking Brake when the module disconnect switch is "ON" and the transmission is placed in "PARK" or "NEUTRAL". It will also advise to Disengage the Parking Brake should the vehicle be placed into gear.
6000-0017	1	<b>SIDE MARKER LIGHT PROGRAMMING</b> The selected side body marker lights are to be programmed to flash with the emergency lighting. Turn signal function is to override this programming.
<b>HVAC</b>		
3000-1616	1	<b>COOLTECH I, F SERIES</b> Install a Cool-Tech I 4-fan 100,000 BTU condenser in the recessed pocket in the roof of the body.
3000-4027	1	<b>12V HVAC, ATTENDANT'S SEAT</b> Install a 12V heat/AC system with brushless motor below the attendant seat.  ** To include a activTek INDUCT 500 installed in the standard duct work.
3000-0427	1	<b>NFPA COMPLIANT VENTING, CAST</b> Install an NFPA style venting system to include a 400cfm exhaust fan along with a static vent. Install 9.5" square polished covers on both vents per drawings.
<b>RADIO</b>		
3000-0432	1	<b>ANTENNA COAX 1 Start: Behind Driver Seat, End: Front Center of Mod Roof</b> An RG 58U coax shall be installed terminating as noted above.
3000-0608	1	<b>ANTENNA COAX 2 Start: Behind Driver Seat, End: Center of Mod Roof</b> An RG 58U coax shall be installed terminating as noted above.
3000-0434	1	<b>3/8" NMO MOUNT COAX 1</b> Supply and install a 3/8" NMO mount in conjunction with specified coax #1.
3000-0618	1	<b>3/8" NMO MOUNT COAX 2</b> Supply and install a 3/8" NMO mount in conjunction with specified coax #2.
3000-1174	1	<b>PULL WIRE 1 Start: Cab Console, End: Inhalation Wall</b> Install a radio cable pull wire terminating as noted above. Wire is not to be wire tied or otherwise prevented from moving freely.
SR00239619	1	TROY FACE PLATE: Quantity: Two (2) #1 For install of Motorola Radios in the front console #2 For install of Motorola Radios in the front console
1000-0411	1	<b>CONSOLE, W/MAP STORAGE, F SERIES</b> Fabricate and install an aluminum cab console and spray with black bedliner material. Console is to include three (3) map/book slots at the rear of the console.
SR00239629	1	Hinged section console -

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
		Install an adjustable console with recessed control panel. It will have a pull knob on the drivers side to release the forward hinged section to be adjustable in various angles.
SR00239597	1	<b>SUPPLY/INSTALL HAVIS # C-ARM-102 ARM RESTS ON EACH SIDE OF THE CAB CONSOLE</b>
1000-0179	1	<b>CUP HOLDERS, 2-TIER</b> Install two (2) two-tier style cup holders recessed into the console.
3000-5156	1	<b>POWER TERMINAL, DUAL, BEHIND DRIVER</b> Install three (3) 10 gauge 30 amp cables to positive and ground studs behind the driver's seat for radio power. Wire one constant hot, one ignition hot and a ground.
3000-5157	1	<b>POWER TERMINAL, DUAL, INSIDE CONSOLE</b> Install three (3) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one constant hot, one battery switched, and the third as a ground.
3000-5033	1	<b>POWER TERMINAL, SWITCHED, INHALATION PANEL</b> Install two (2) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one battery switched and the other as a ground.
<b>OXYGEN</b>		
4000-0165	1	<b>O2 MOUNT, VERTICAL TRACK FOR QRM-V</b> Vertical track for mounting of a QRM-V O2 bottle mount shall be welded on the back wall of the streetside forward compartment in the right hand corner. Bracket will be set up for an 'H' sized bottle.
4000-0166	1	<b>O2, CYLINDER BRACKET: ZICO QRM-V</b> Install a Zico QRM-V oxygen bracket for 'H' bottle. Locate in the streetside forward compartment.
4000-0022	3	<b>O2 OUTLET, OHIO MEDICAL (2) In Main wall action area, (1) Head end of the curbside upper cabinet.</b> Install O2 outlets per instructions above. Outlets to be Ohio Medical style.
4000-0025	1	<b>OXYGEN WRENCH</b> Install oxygen wrench in oxygen compartment. Mount securely to wall. Mount with length of chain or cable to allow for use without being removed from the compartment.
4000-0103	1	<b>D MOUNT: QR-D-2, STRAPLESS UNDER BENCH HEAD LOC 2</b> Install a Zico QR-D-2 Quic-release strapless d-cylinder oxygen bracket.
3000-0642	1	<b>VACUUM OUTLET, OHIO MEDICAL 1 In Inhalation Area</b> Install a single Ohio style vacuum outlet. Locate per drawings.
4000-0179	1	<b>ASPIRATOR, SSCOR, INHALATION AREA</b> Install an SSCOR aspirator. The system shall include a wall mounted regulator and a canister holder. Plumb to the selected pump.
4000-0089	1	<b>VACUUM PUMP CAPL #D34 SE (P282)</b> Install a CAPL #D34 SE (P282) 12vdc electric suction pump.
4000-0076	1	<b>D MT: QR-D-2, STRAPLESS Under Bench Head LOC 1</b> Install a Zico QR-D-2 Quic-release strapless d-cylinder oxygen bracket.
<b>CERTIFICATIONS</b>		

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**

Option	QTY	Description
7000-0001	1	<b>KKK-A-1822F CERTIFICATION LABEL</b> The vehicle shall have weight/payload, electrical load and KKK-A-1822F certification stickers installed in the O2 compartment.
7000-0003	1	<b>CHANGE NOTICE 10 CERTIFICATION</b> The vehicle shall be certified to change notice 10 standards.

Spec Writer: **John Cox**

Spec Designer:

**Albany Fire Department**